

## Article 479



**Materia prima: Ottone**  
**Funzionamento: Acqua calda**

Si è elaborato il seguente manuale d'uso allo scopo di fornire le informazioni appropriate per l'installazione e le precauzioni da adottare da parte dell'installatore e dell'utilizzatore. Il costruttore declina ogni responsabilità in caso di utilizzo dell'apparecchio al di fuori delle istruzioni fornite.

**ATTENZIONE:** Questo apparecchio può essere utilizzato solo per supporto di asciugamani o simili. L'apparecchio nel suo normale utilizzo non deve essere caricato con un peso superiore a **5Kg**

Utilizzare solo le viti e i tasselli in dotazione o sostituirli con altre di uguali o maggiori caratteristiche di tenuta meccanica

**GRADO DI PROTEZIONE:** Apparecchio protetto contro gli spruzzi.

**CONTENUTO DELLA CONFEZIONE:** (vedi immagine 1)

- (2) Guarnizioni
- (2) Eccentrici
- (2) Rosoni
- (1) Manuale d'uso e istruzioni

**INSTALLAZIONE:** (vedi disegno 2)

1. Rimuovere lo scaldasalviette e i suoi componenti dall'imballo

2. Fare predisporre dall'installatore due attacchi a muro orizzontali F. da 1/2" con interasse di 1166mm
3. Dopo aver avvolto gli eccentrici con canapa o teflon, avvitare gli stessi sui raccordi a muro F. da 1/2".
4. Inserire la guarnizione esente amianto verde sulla sede del rubinetto e far scorrere il rosone sulla calotta.
5. Avvitare i corpi dei rubinetti agli eccentrici.
6. Ad apparecchio installato, si consiglia di sfiatare (svitare leggermente la vite di sfiato) più volte fino a totale fuoriuscita dell'aria, agendo sugli sfiati posti alle estremità superiori dello scaldasalviette
7. Ove tutti gli elementi non raggiungessero la temperatura di esercizio, si consiglia di ripetere l'operazione dopo qualche minuto.

**Raw material : Brass**  
**Operation: Hot water**

The following manual has been elaborated in order to supply all the useful information for a correct installation together with the precautions to adopt both from installer and users. **Manufacturer declines every responsibility in case of different uses from these instructions.**

**ATTENTION :** This item can be only used as holder for towels and similar garments. This item, in normal use, cannot be loaded with more than **5 Kg.** weight.

Please, only use provided screws and dowels or replace them with other ones equivalent or greater in mechanical characteristics.

**PROTECTION DEGREE:** Squirts resistant.

**PACKING CONTENTS:** (see image 1)

- (2) Green gaskets
- (2) Eccentric
- (2) Wahser
- (1) Instruction & Operation Manual

**INSTALLATION:** (see design 2)

1. Take out the heated towel rail and its components from the package.

2. Let the plumber predispose two horizontal F 1/2 " connections out coming from the wall with 1166mm distance between hole centres.
3. After wrapping the eccentric nipples with hemp or teflon, screw them to the wall out coming F 1/2 " connections.
4. insert the amiantus free gasket upon the tap basis and let the wahser slide on the nipple.
5. Screw the tap bodies to the eccentric nipples.
6. When the item is installed, it is suggested to vent it more times until air (to slightly screw the leaking valve off) has completely gone out from the pipes, using the breathing valves on the top of the heated towel rail.
7. If not all bars reach the expected temperature, you would have better repeat the operation after a few minutes.

1)



2)

