



Vieser maintenance guide



How to clean Vieser drain

- Clean excess dirt from the frame.
- Remove the water trap from the floor drain by lifting the blue handle.
- If the water trap in the drain does not have a handle, take hold of the lower part of the water trap. Bend the lower edge slightly towards the outlet pipe and lift the water trap out in a tilted position.
- If the water trap has not been removed for a long time, it may be tight.
- The flow regulator of the side inlets in the water trap can also be removed for cleaning.
- Clean the water trap and floor drain thoroughly and rinse.

After cleaning

- Check that the water trap's grey lip seal is in place and moisten it with soapy water, for example.
- Install the water trap back into the floor drain and check that it is properly in place. Be sure to also reinstall the flow regulator in the water trap.
- Press the grating back into place.

The drain may emit an unpleasant odour

- If the water trap is not properly in place.
- If the water trap seal is damaged.
- If the drain is dirty.

Cleaning the Vieser grating

- Clean the the grating on both sides and remove accumulated dirt.
- Clean any stubborn dirt from stainless steel grating by rubbing it gently.
- Calcium buildup is easiest to remove gently with an acidic cleaning agent.

The floor drain should be cleaned if the water flow slows down or the drain begins to smell. We recommend cleaning at least once a year.

Vieser Oy, Keskustie 23 61850 Kauhajoki
Puh. +358 20 746 4400